# Temperature Sensor

The temperature sensor is an accessory that enables up to three simultaneous temperature measurements. Temperature thresholds can be established on the Chariot Smart Drive configuration and it allows you to combine these settings with other conditions to get highly customized event reporting.

010011
101001
000100

highly configurable

Establish thresholds
and manage alerts.

frequent reporting

Regulate temperature
monitoring.

event alerts

Keep well informed with notifications via
email or SMS as they occur.

KEY FEATURES INCLUDE:

- Report temperature values periodically and on any event generated
- Establish thresholds and create events when the temperature falls below or above these thresholds
- Perform different actions based on those thresholds (for example, activate outputs and send notifications such as email notification and SMS)